



SERVICE INSTRUCTION

Technical overview and operations
maintenance of fire extinguishers powder
GPX

IS - 2
Issue 07
Date ed. 01.2016

Instruction is in accordance to PN-EN on fire extinguishers, to a project of PN-EN 12367 "Fire extinguisher - Maintenance" and the proposals contained in the International Standard ISO 11,602 - 2 developed by the Technical Commission ISO / TC 21 "technical means and facilities for fire protection subcommittee SC 2" Fire extinguisher "

Instruction is designed in accordance with the requirements of the "Regulation of the Minister of Internal Affairs and Administration of 21 April 2006 (Journal of Laws No. 80 poz.563) on fire protection of buildings, other buildings and sites.

REVIEW, MAINTENANCE, REPAIR, LIQUIDATION

Instruction covers all technical and administrative activities, including surveillance activities, to maintain equipment in, or return to the state, in which it can fulfill the required functions. These activities are designed to "restore the pattern, which has been certified by the fire extinguisher in Jozefow CNBOP. The scope of actions to maintain the readiness of fire extinguishers include:

1. Control - made by the owners, users

- Check if the extinguisher is in place for that purpose;
- Is not blocked and easily available;
- Has a readable label instructions;
- It is not visibly damaged;
- Has the seal intact and indicators;
- Pressure gauge works properly;
- Is of suitable type and size of filling;
- If the extinguisher has been approved for maintenance, must be replaced by a fire extinguisher of the same type of fires and to the same group and at the same fire extinguishing efficiency.

Frequency of inspections by the user should not be less than every quarter.

2. Overview – Trained conservator (serviceman) keep an extinguisher in good condition.

Lp	Item name	Requirements	Frequency steps
1	Cylinder	<ul style="list-style-type: none"> - Check the overall condition of the cylinder; - Date of manufacture and durable markings; - State of varnish coating (covered with corrosion extinguisher must be scrapped); - Condition and readability of the label. 	In accordance with the instructions set by the manufacturer but not less frequent than every 12 months
2	Valve, manometer	<ul style="list-style-type: none"> - Check the external components (condition of levers, body, etc.); - Check the seal; - Check if there is no trace of powder in the body and in the front of valve; - Check the condition of the pressure inside of tank through a control manometer or pressure gauge performance. 	In accordance with the instructions set by the manufacturer but not less frequent than every 12 months
3	Hose	<ul style="list-style-type: none"> - Check the technical condition (cracks in the outer shell, the condition of endings and terminals); - Check the patency; - Check in accordance with the completion certificate issued 	In accordance with the instructions set by the manufacturer but not less frequent than every 12 months
4	Fire-extinguishing powder	<ul style="list-style-type: none"> - Check the status of powder by repeated movement of powder inside the extinguisher and declare whether it is flowing; - Make the entire fire extinguisher weighing in order to verify the quantity of extinguishing agent (compare with documentation) 	In accordance with the instructions set by the manufacturer but not less frequent than every 12 months

3. Repair – when the essential elements of fire extinguishers have been damaged or term of validity of an extinguishing agent expired;
 Repair is performed by the authorized maintenance person

Lp.	Item name	Requirements	Frequency
1	Cylinder	<ul style="list-style-type: none"> - Check the overall condition of the cylinder; - Date of manufacture and durable markings; - State of varnish coating (in case of severe corrosion extinguisher must be scrapped); - condition and readability of the label; - Slowly unscrew the valve, allowing the descent of the pressure get of the cylinder; - Empty cylinder with extinguishing powder; - For cylinders with capacity more than 6 liters of water, tests from UDT (of the external, internal, pressure test revision); - The research cylinder dry thoroughly; - Fill with proper powder, in accordance with a certificate issued by CNBOP on one type of fire extinguisher 	Every 10 years
2	Valve	<ul style="list-style-type: none"> - Unscrew the valve from the cylinder; - Unscrew the deep tube and check the patency; - Check the condition of spring, in the case of corrosion change to a new; - Thoroughly cleaned and, if necessary, wash and dry the valve; - Replace the rubber seals on plunger and body; - Check the condition of the body surface to the fact the occurrence of mechanical damage or cracks; - Check the condition of the thread; - Assemble the valve according to the documentation. 	Every 10 years or if an ealier use, or damage
3	Hose	<ul style="list-style-type: none"> - Check the technical condition (cracks in the outer shell, the state of endings and terminals), in case of damage change to a new one; - Check the patency; - Check the completion according to the issued certificate 	Every 10 years or at the time of injury
4	Fire-extinguishing powder	<ul style="list-style-type: none"> - Carefully pour out the old powder; - Re-fill with a new, according to the certificate - Mixing with other powder is not allowed 	Every 10 years or, if an earlier use

4. Liquidation - elimination of the fire extinguisher which is not suitable for maintenance.

Lp.	Item name	Control Requirements	Frequency
1	Cylinder	Liquidation carried out in the following cases: - Penetration of the pressure in the tank; - Corrosion on a substantial part of the tank; - Riveted tanks; - bad threaded connections; - Negative test UDT	
2.	Valve	- In the case of mechanical damage or a lack of spare parts;	
3	Hose	- Cracks in the outer shell; - Damage to the terminal or terminals	
4	Fire-extinguishing powder	- Lack of powder in accordance with the certificate; - lumpy (hardened) powder; - Too much moisture; - Mechanical and chemical contamination.	

5. The statement of work performed:

Once carried out the inspection and maintenance, authorized factory should give certification for above works. The proof of completion of these actions is also information on control label, which should include:

- Type of service activities (review, maintenance, repair);
- Name and address of the executing maintenance service;
- The competent person data;
- Date (year and month) of performed maintenance operations;
- Date (year and month) of the next test.

6. The list of key legislation and standards:

- Regulation of the Minister of Internal Affairs and Administration of 21 April 2006 (Journal of Laws No. 80 item. 563);
- PN-EN for fire extinguishers;
- Project of PN-EN 12,367 portable fire extinguishers - maintenance;
- Law on Waste.

WARNING! For service work use only tools approved by the KZWM Ogniochron company.

During the examination, maintenance and repair use only original spare parts and extinguishing agents used by manufacturers for fire extinguishers production.

Technical condition of the fire extinguisher after repair examination must exactly match the pattern, for which manufacturers have received attest or certificate. For not complying with this rule, criminal sanctions will be used, according to the Fire prevention act.